CAR BLACK BOX

Manual



















CAR BLACK BOX

Manual

Congratulations for purchasing our mobile DVR products, before connecting, operating or adjusting this product, please read these instructions compactly to make you particular mobile multimedia products to best perform

- 1. Do not repair it by yourself, if any trouble occurs, please immediately shuts it off and contact our company or local dealer. This car black box is composed of many precise electronic components, any detachment or reassembling may result
- 2. Do not exposed it in humid air, dust, vapor, oil lampblack, sunlight,
- 3. Do not use thinner or any other chemical cleaner. Please choose soft cloth to clean the dirt on the camera.
- 4. Keep the DVR far from extremely heating or cooling places. Storage temperature: -30~80°C Operating temperature: -20-70°C
- 5. Prevent the set from falling or struck.

CAUTION:

- 1. Please mind the intervening time between pressing buttons should be no less than 0.5s while operating function setup.
- 2. After DC power is on, it should be no less than 20s before power off, just in order to give suitable charging time to built-in battery.
- 3. Please cut DC power off while using reset button While encounting following condition, please use reset button to reset and continue working.
- A, after DC power is on, only indicator light of battery is on, all others are off.
- B, when button misoperation cause DVR crashed or back screen, cut power off and get power on again, it still can't startup all right.

SPECIFICATION

Built-in 5,000,000 pixels high resolution camera.

System: PAL/NTSC compatible.

Recording resolution: 1280×720 / 960×720 / 640×480.

Recording frame rate: 60/50/40/30 fps.

Supports real time playback.

Recording mode: automatic records when car power is on. After power off, the built-in Li-ion battery will provide power 10s to save

data and prevent video files loosing. Then it will automatically stop work.

Record image + time + data.

Built-in microphone.

Circular records automatically, over-write if memory is full.

Supports up to 32G SD card.

USB port: hasn't added any function to it yet.

Car cigarette lighter power supply, easy installation.

Cigarette Lighter: 12~24V

Working voltage/current: DC 5V/400mA.

Factory setup: Resolution: 1280 × 720, Time slice (min): 1 Video backup: turn off power, remove SD card, and then insert it

into the SD card slot of computer to read and backup.

You'd better use SDHC card.

SD CARD MENU SETUP

Putting the setup file into SD card can change the parameter setup of the product. The setup file will automatically been deleted after executing one time. If the parameters need to be reset, please put the setup file into SD card again.

Name of setup file: cbbconfig.txt

Location of setup file: put the setup file to the root directory of SD card, such as H:\cbbconfig.txt

Format of setup file: 013001020091214092700

Character representation of the format: 1st and 2nd: Resolution (01, 02, 03)

01=1280×720 02=960×720 03=640×480 3rd and 4th: Frame rate (30, 40, 50, 60)

5th and 6th: Slice time (01, 02, 03 ... 40, 50, 60)

7th: PAL/NTSC 0= PAL, 1= NTSC

8th and more: Date time (Year/Month/Date/Hour/Min/Sec)

OPERATION DECLARATION:


Pull in the cigarette lighter, it starts to work automatically, and enter into record mode, the REC red dot appears.



1. Press "REC" button, it stops record, the REC red dot will disappear.

REC	00:36:29

Press "REC" button again, it starts to record again.



OPERATION DECLARATION:

2. In state of stop record

Press "MENU" button, enter into "Setup Mode"

First Mode	Video
Time Setup	Enter
Resolution	1280*720/960*720/640*480
Time slice(min)	1/2/3/4/5/6/7/8/9/10/20/30/40/50/60
Frame(fps)	30/40/50/60
Save&Exit	Save&Exit

Press it the second time, enter into "Play Mode"



Press the third time will enter into *Record Mode



The three modes cycle continue when repeating the operation.


OPERATION DECLARATION:

Setup Mode

First Mode Time Setup Resolution 1280*720/960*720/640*480 1/2/3/4/5/6/7/8/9/10/20/30/40/50/60 Time sline(min) Frame(fps) Save&Exit Save&Evit

Press "REC" button to move down options, then press "MENU" button to select specific values. Move to "Save & Exit" option to save and exit after selection finished.

3. Play Mode



Press "REC" button to select recording file, then press "PLAY" button to play single video file, press it again will pause.

4. In any state, press "PLAY" button two seconds, it will save the files and automatically power off in three seconds, then pull out the cigarette





- 1. AV out
- 2. DC 5V input
- 3. USB (hasn't added any function to it yet.)
- 4. Recording
- 5. Menu
- 6. Play
- 7. SD card slot
- 8. Power pilot lamp 9. Battery pilot lamp
- 10. Recording pilot lamp
- 11. Reset button (remove cigarette lighter and pull it in again, then press "Reset button", it will starts to work again.)
- 12. Microphone